
1) Connect VIN to BAT for:
Lipo Battery Power or
Lipo Battery Power & Charging from Wall or USB

2) Connect VIN to WALL for No Battery & 5V Wall or USB Power

3) No jumper to turn off node





USB INPUT

Micro Lipo Charger